


Upper Header

Lower Header



For construction with wall studs on 16 in. centers, the header is located between the studs for the right side mounting. For construction with wall studs on centers greater than 9 1/2 in. provide secure header as shown.

**IMPORTANT**  
These models do not come with built-in switch; one must be provided

Wire cover tube fits into centre of cover plate which fits over single gang box

1 1/4

3 1/2

# JEEVES D STRAIGHT - 16