


For construction with wall studs on 16 in. centers, the header is located between the studs for the right sidemounting.
 For construction with wall studs on centers greater than 19-1/2 in. provide secure header as shown.



IMPORTANT
 These models do not come with built-in switch; one must be provided

Wire cover tube fits into centre of cover plate which fits over single gang box

JEEVES H CURVED - 16