


For construction with wall studs on 16 in. centers, the header is located between the studs for the right sidemounting. For construction with wall studs on centers greater than 19-1/2 in. provide secure header as shown.



IMPORTANT
These models do not come with built-in switch; one must be provided

Wire cover tube fits into centre of cover plate which fits over single gang box

**JEEVES
H CURVED - 24**